2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

2007 ACCESSORIES & EQUIPMENT

Interior Trim and Paneling - H3

SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

Fastener Tightening Specifications

Specification		ication
Application	Metric	English
Sunshade Bolt	2 N.m	18 lb in
Rear Side Door Armrest Bracket Bolt	10 N.m	89 lb in
C Pillar Assist Handle Bolt	52 N.m	38 lb ft
Assist Handle Bolt	9 N.m	80 lb in
Rear Seat Cup Holder Screw	2 N.m	18 lb in
Upper Body Side Garnish Screw	2 N.m	18 lb in
Windshield Side Garnish Screw	9 N.m	80 lb in
Door Trim Panel Screw	2 N.m	18 lb in
Door Trim Panel Bolt	9 N.m	80 lb in
Sunshade Screw	2 N.m	18 lb in

REPAIR INSTRUCTIONS

DOOR INSIDE HANDLE BEZEL REPLACEMENT




Fig. 1: Removing/Installing Door Inside Handle Bezel

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

Courtesy of GENERAL MOTORS CORP.

Door Inside Handle Bezel Replacement

Callout	Component Name
1	Front Side Door Armrest Finish Cover

FRONT SIDE DOOR TRIM PANEL REPLACEMENT




Fig. 2: Removing/Installing Front Side Door Trim Panel Courtesy of GENERAL MOTORS CORP.

Front Side Do	or 1rim Panei Replacement
Callout	Component Name
Preliminary F	rocedure
1. Remove i	inside handle bezel. Refer to Door Inside Handle Bezel Replacement .

2. Remove the door window switches. Refer to **Door Lock and Side Window Switch** Replacement - Driver Side (1st Design) or Door Lock and Side Window Switch Replacement - Driver Side (2nd Design) or Door Lock and Side Window Switch Replacement - Passenger Side .

2007 Hummer H3 2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

1	Trim Bolt Accessory Hole Cover
	Door Trim Panel Screw
	NOTE:
2	Refer to <u>Fastener Notice</u> .
	Tighten: 2 N.m (18 lb in)
	Door Trim Panel Bolt (Qty: 2)
3	
	Tighten: 9 N.m (80 lb in)
	Side Door Trim Panel Assembly
	Tip:
4	Release the inside door handle cables. Refer to <u>Front Side Door</u> <u>Inside Handle Replacement</u> .
	2. Disconnect the electrical connectors.
5	Side Door Trim Panel Retainer (Qty: 9)

REAR SIDE DOOR TRIM PANEL REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 3: Trim Panel Replacement - Side Rear Door Courtesy of GENERAL MOTORS CORP.

Rear Side Door Trim Panel Replacement

Callout	Component Name
NOTE:	
Refer to Fastener	Notice .
Fastener Tight Preliminary P	tening Specifications: Refer to <u>Fastener Tightening Specifications</u> . rocedure
1. Remove in	side handle bezel. Refer to Door Inside Handle Bezel Replacement .
2. Remove th	ne door window switches. Refer to Rear Side Door Window Switch
Replacem	<u>ent</u> .
1	Cover, Trim Bolt Accessory Hole
2	Screw, Door Trim Panel

2007 Hummer H3
2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

	Tighten: 2 N.m (18 lb in)
	Bolt, Door Trim Panel (Qty: 2)
3	
	Tighten: 9 N.m (80 lb in)
	Panel Assembly, Side Door Trim
4	Tip: Release the inside door handle cables. Refer to Front Side Door
	Inside Handle Replacement .
5	Retainer, Side Door Trim Panel (Qty: 7)

FRONT SIDE DOOR WATER DEFLECTOR REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 4: Water Deflector Replacement - Front Door Courtesy of GENERAL MOTORS CORP.

Front Side Door Water Deflector Replacement

Callout	Component Name	
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.		
Preliminary I	Preliminary Procedure:	
Remove the interior trim panel. Refer to Front Side Door Trim Panel Replacement .		
	Deflector Assembly, Front Side Door Water Tip: Carefully pull the water deflector away from the door while feeding	

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

any wiring or connectors through the water deflector.

REAR SIDE DOOR WATER DEFLECTOR REPLACEMENT




Fig. 5: Water Deflector Replacement - Rear Door Courtesy of GENERAL MOTORS CORP.

Rear Side Door Water Deflector Replacement

Callout	Component Name	
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.		
Preliminary 1	Preliminary Procedure:	
Remove the interior trim panel. Refer to Rear Side Door Trim Panel Replacement .		
	Deflector Assembly, Rear Side Door Water	
1	Tip: Carefully pull the water deflector away from the door while routing any	
	wiring or connectors through the water deflector.	

ARMREST BRACKET REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3





Fig. 6: Armrest Bracket Replacement Courtesy of GENERAL MOTORS CORP.

Armrest Bracket Replacement

Callout	Component Name
NOTE:	
Refer to Fastener	Notice .
	ening Specifications: Refer to <u>Fastener Tightening Specifications</u> .
Preliminary Pr	ocedures
1. Remove th	e interior trim panel. Refer to Rear Side Door Trim Panel Replacement .
2. Remove th	e water deflector. Refer to Rear Side Door Water Deflector
Replacem	<u>ent</u> .
	Bolt, Rear Side Door Armrest Bracket (Qty: 2)
1	
	Tighten: 10 N.m (89 lb in)
2	Bracket, Rear Side Door Armrest

COWL SIDE TRIM PANEL REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3







Fig. 7: Cowl Side Trim Panel Replacement Courtesy of GENERAL MOTORS CORP.

Cowl Side Trim Panel Replacement

Callout	Component Name	
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.		
Preliminary I	Preliminary Procedures:	
Remove the front door sill trim plate. Refer to Front Side Door Sill Plate Replacement .		
1	Panel, Cowl Side Trim	
2	Clip, Panel Cowl Side Trim (Qty: 2)	

FRONT SIDE DOOR SILL PLATE REPLACEMENT



2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

Fig. 8: Front Side Door Sill Plate Replacement Courtesy of GENERAL MOTORS CORP.

Front Side Door Sill Plate Replacement

Callout	Component Name
Fastener Tigl	ntening Specifications: Refer to Fastener Tightening Specifications.
1	Plate Assembly, Front Side Door Sill Trim
2	Clip, Door Trim (Qty: 3)

REAR SIDE DOOR SILL PLATE REPLACEMENT




Fig. 9: Rear Side Door Sill Plate Replacement Courtesy of GENERAL MOTORS CORP.

Rear Side Door Sill Plate Replacement

Callout	Component Name	
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.		
Preliminary Procedures:		
Remove the fr	ont door sill trim plate. Refer to Front Side Door Sill Plate Replacement .	

2007 Hummer H3 2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

1	Plate Assembly, Rear Side Door Sill Trim
2	Clip, Rear Side Door Sill Trim (Qty: 4)

LIFTGATE DOOR SILL PLATE REPLACEMENT




Fig. 10: Liftgate Door Sill Plate Replacement Courtesy of GENERAL MOTORS CORP.

Liftgate Door Sill Plate Replacement

Callout	Component Name
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.	
1	Plate Assembly, Rear Door Sill Trim
2	Clip, Rear Door Sill Trim (Qty: 10)

ASSIST HANDLE REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 11: Assist Handle Replacement
Courtesy of GENERAL MOTORS CORP.

Assist Handle Replacement

Callout	Component Name	
Preliminary	Preliminary Procedures	
	e the lower center pillar trim panel. Refer to <u>Center Pillar Lower Trim</u> Replacement.	
	e the upper center pillar trim panel. Refer to Center Pillar Upper Trim	
Panel F	Replacement.	
1	C Pillar Assist Handle Bolt (Qty: 2) NOTE:	
1	Refer to <u>Fastener Notice</u> . Tighten: 52 N.m (38 lb ft)	
2	C Pillar Assist Handle Assembly	

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

ROOF RAIL REAR ASSIST HANDLE REPLACEMENT




Fig. 12: Roof Rail Rear Assist Handle Replacement Courtesy of GENERAL MOTORS CORP.

Roof Rail Rear Assist Handle Replacement

Callout	Component Name
NOTE:	
Refer to Fastener	Notice .
Fastener Tight	ening Specifications: Refer to Fastener Tightening Specifications.
1	Assist Handle Filler
2	Assist Handle Bolt (Qty: 2)
2	Tighten: 9 N.m (80 lb in)
3	Assist Handle Assembly

SUNSHADE REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 13: Sunshade Replacement Courtesy of GENERAL MOTORS CORP.

Sunshade Replacement

Callout	Component Name
	Sunshade Screws (Qty: 2)
1	NOTE: Refer to <u>Fastener Notice</u> .
	Tighten: 2 N.m (18 lb in)
2	Sunshade Assembly
	Tip: Disconnect the electrical connector, if equipped.

SUNSHADE ANCHOR REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 14: Sunshade Anchor Replacement
Courtesy of GENERAL MOTORS CORP.

Sunshade Anchor Replacement

Callout	Component Name
	Sun Shade Bolt
1	NOTE: Refer to <u>Fastener Notice</u> .
	Tighten: 2 N.m (18 lb in)
2	Sun Shade Assembly Support
2	Tip: Disconnect the electrical connector, if equipped.

WINDSHIELD PILLAR GARNISH MOLDING REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 15: Windshield Pillar Garnish Molding Replacement Courtesy of GENERAL MOTORS CORP.

Windshield Pillar Garnish Molding Replacement

Callout	Component Name
Preliminary	Procedures:
Disable SIR	system. Refer to SIR Disabling and Enabling .
1	Windshield Side Garnish Bolt Hole Finish Plug
2	Windshield Side Garnish Screw
	NOTE:
	Refer to <u>Fastener Notice</u> .

2007 Hummer H3 2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

	Tighten: 9 N.m (80 lb in)
2	Windshield Side Garnish Molding Assembly
3	Tip: Disconnect the electrical connector.

BODY SIDE REAR UPPER GARNISH MOLDING REPLACEMENT




Fig. 16: Body Side Rear Upper Garnish Molding Replacement Courtesy of GENERAL MOTORS CORP.

Body Side Rear Upper Garnish Molding Replacement

Callout	Component Name
1	Upper Body Side Garnish Bolt Hole Finish Plug
	Upper Body Side Garnish Screw
2	NOTE:
2	Refer to <u>Fastener Notice</u> .
	Tighten: 2 N.m (18 lb in)
3	Upper Body Side Garnish Molding Assembly
4	Upper Body Side Garnish Retainer (Qty: 9)

CENTER PILLAR UPPER TRIM PANEL REPLACEMENT

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 17: Upper Center Pillar Trim Panel Replacement Courtesy of GENERAL MOTORS CORP.

C Pillar Upper Trim Panel Assembly

Center Pillar Upper Trim Panel Replacement

Center I mar e	Center I mai Opper I i mi I anei Kepiacement		
Callout	Component Name		
Fastener Tight	Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.		
Preliminary Programme 1. Remove the	rocedures ne front seat belt. Refer to Seat Belt Retractor Pretensioner		
<u>Replacem</u>	nent - Front .		
2. Remove th	2. Remove the lower center pillar trim panel. Refer to Center Pillar Lower Trim		
Panel Re	Panel Replacement.		

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

2 C Pillar Upper Trim Clip (Qty: 2) **Tip:** Ensure the tab on the top of the trim panel is secured.

CENTER PILLAR LOWER TRIM PANEL REPLACEMENT




Fig. 18: Lower Center Pillar Trim Panel Replacement Courtesy of GENERAL MOTORS CORP.

Center Pillar Lower Trim Panel Replacement

Callout	Component Name
Fastener Tigl	ntening Specifications: Refer to <u>Fastener Tightening Specifications</u> .
1	Panel Assembly, Trim Center Pillar Lower
2	Clip, Center Pillar Lower Trim panel (Qty: 4)

BODY SIDE TRIM PANEL REPLACEMENT - LEFT SIDE




Fig. 19: Left Body Side Trim Panel Replacement Courtesy of GENERAL MOTORS CORP.

Body Side Trim Panel Replacement - Left Side

Callout		Component Name		
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.				
Preliminary Procedures				
1.	Remove th	ne rear door sill trim plate. Refer to Rear Side Door Sill Plate		
	Replacem	<u>nent</u> .		
2.	Disconnec	t the rear seat belt. Refer to Rear Seat Belt Retractor Replacement .		
3.	Remove th	ne rear body side upper trim. Refer to Body Side Rear Upper Garnish		
Molding Replacement.				
	1	Panel Assembly, Body Side Lower Trim		
		Tip: Pull the seat belt through the trim panel.		
	2	Retainer, Body Side Lower Trim Panel (Qty: 11)		

BODY SIDE TRIM PANEL REPLACEMENT - RIGHT SIDE

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3




Fig. 20: Right Body Side Trim Panel Replacement Courtesy of GENERAL MOTORS CORP.

Body Side Trim Panel Replacement - Right Side				
Callout	Component Name			
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.				
Preliminary I	Procedures			
1. Remove t	the rear door sill trim plate. Refer to Rear Side Door Sill Plate			
<u>Replacer</u>	<u>nent</u> .			
2. Disconne	2. Disconnect the rear seat belt. Refer to Rear Seat Belt Retractor Replacement .			
3. Remove t	3. Remove the rear body side upper trim. Refer to Body Side Rear Upper Garnish			
Molding Replacement.				
	Panel Assembly, Body Side Lower Trim			
	Tip:			
1				
	1. Disconnect the accessory power outlet connector.			
	2. Pull the seat belt through the trim panel.			
2	Retainer, Body Side Lower Trim Panel (Qty: 10)			

2007 ACCESSORIES & EQUIPMENT Interior Trim and Paneling - H3

ENDGATE TRIM PANEL REPLACEMENT




Fig. 21: Endgate Trim Panel Replacement Courtesy of GENERAL MOTORS CORP.

Endgate Trim Panel Replacement

Enigate 11mi i anci Repiacement				
Callout	Component Name			
Fastener Tightening Specifications: Refer to Fastener Tightening Specifications.				
Preliminary Procedure:				
Remove the lower liftgate trim finish panel.				
1	Lower Trim Finish Panel Assembly Lift Gate			
2	Liftgate Lower Trim Finish Panel Retainer (Qty: 10)			
3	Upper Trim Finish Panel Assembly Lift Gate			
4	Liftgate Upper Trim Finish Panel Retainer (Qty: 12)			